


КРАКА ЗА КУХНЕНСКИ ШКАФОВЕ

КРАК




02.A100 - крак H100
02.A120 - крак H120
02.A150 - крак H150

КРАК РАЗГЛОБЯЕМ



31.A100 - крак H100
31.A120 - крак H120
31.A150 - крак H150
05.0360 - база за крак разглобяем

КРАКА ЗА РЕГУЛИРАЩ КЛЮЧ



05.0500 - основа за крак
04.D060 - крак H60
04.D100 - крак H100

1501002 - регулиращ ключ
за крак 04.D

ОСНОВА ЗА КРАК Ф80




КРАК Ф80



05.212000


21.0080-крак ф80, H80
21.0100-крак ф80, H100

ЩИПКА ЗА АЛУМ./PVC ЦОКЪЛ




06.151

ЩИПКА ЗА КРАК Ф80




06.213110

ЩИПКА ЗА ЦОКЪЛ ПДЧ



06.162

ДЪНО ЗА ВГРАДЕН ХЛАДИЛНИК



73.A08